



WHITE FEET- Cool Roof Tiles

Laying Instructions

- 1) Prepare base mortar with cement and sand in the ratio 1:4 along with waterproofing chemical
- 2) The total mortar thickness should not be more than 25mm
- 3) Keep the hand mixer ready to apply to avoid uneven surface, while laying the tile
- 4) Prepare cement slurry as thick paste to spread on the mortar
- 5) Use 6mm spacer in between tiles
- 6) Do not use hammer for laying
- 7) Fill the joints with white cement, sand and waterproofing chemical or use suitable water proofing grouting Material;
- 8) Do not use the layed area for 48 hours